



# Markforged Mark Two: Changing the Fiber Reinforcement Filament

Learn how to change the fiber reinforcement filament on the Markforged Mark Two.

Written By: Nico Willem Lagendyk



## Introduction

This guide will explain how to change the fiber reinforcement filament for the Markforged Mark 2 printers.

Sources:

- [Markforged Guide: Unload Fiber Desktop](#)
- [Markforged Guide: Load Fiber Desktop](#)




Pictures by: Ashley Recklein, Nico Lagendyk



### TOOLS:


- [Side Cutter](#) (1)
  - [Tweezers](#) (1)
  - [Scale](#) (1)
  - [Tape](#) (1)
-

## Step 1 — Unloading Fiber



- Select the **Menu** from the dashboard of the printer
- Select **Materials**
- Select **Unload Fiber**
- Click **Next** to continue

## Step 2 — Unloading Fiber II



- Carefully wind the remaining **fiber** back onto the **spool**
- Tape the end of the **fiber filament** to keep it from unspooling
- Place the spool in the small bronze colored bag with the same fiber name
- Click **Next**



 **Be cautious with spools of reinforcement as careless handling can result in fiber splinters**

### Step 3 — Set up Fiber for Loading




- Remove the **spool** from the bag
- If it is a *partial* **spool** weigh it in grams and make a note of it for later
- Carefully unwind two and a half feet of material from the **spool**
- Re-apply the tape to keep the rest of the material from unspooling
- Feed the cut end of the material through the fiber feed tube until it reaches the fiber extruder

### Step 4 — Load Fiber




- Select the **menu** icon from the dashboard
- Select **Materials**
- Select **Load Fiber**

## Step 5 — Load Fiber II



- Select **Meter Load** on the printer's touchscreen
- Select the fiber you are loading into your printer
- Select the type of spool you are loading
  - ❗ This information is on the spool's label as well as its bag label



## Step 6 — Load Fiber III




- For partial spool's enter in the weight measured before
- Feed the **Fiber** into the feed tube until the extruder catches it
- Place the **fiber** on the **spindle** and attach the magnetic **cap**
- Once under *tension*, remove the **tape**

**⚠ Releasing the tape before the fiber is in tension will unspool the fiber and could waste material or hurt you**

## Step 7 — Load Fiber IV



- Once the fiber is extruding, press **Cut**  
 **Pressing Cut too soon will likely result in a fiber jam**
- Use tweezers to remove the extruded material from the nozzle
- If the routine times out, restart the fiber loading procedure by pressing **Retry**
- Press **Done** on the touchscreen to finish the utility