




Formlabs Form 3+: Changing Resin Cartridge and Tank

A guide explaining how to change materials on the Formlabs Form 3+ printers.


Written By: Anton Brian Preslopsy



Introduction

Source: [Inspecting the Tank](#)



Step 1 — Removing Cartridge



⚠ Put on nitrile gloves and keep them on throughout this entire process


- Retrieve the empty resin tank box and the new resin tank box you will be putting in the machine
- Take the orange nipple cap and tank cover out of the empty box
 - ⓘ The orange nipple cap is used to keep the resin from dripping out of the nipple on the bottom of the **resin cartridge** when it is being stored
- Push down the cap of the **resin cartridge** if it is not already closed
- Pull the **resin cartridge** straight up using the indent in the back of the container

Step 2 — Storing Cartridge



- Clean the nipple on the bottom of the **resin cartridge** with a paper towel
- Place the orange nipple cover on the nipple
- Place the **resin cartridge** in the specified storage location

Step 3 — Removing Tank



- Grip both sides of the resin tank and pull backwards
- After you feel the tank pop out it should be safe to lift up and out to store

Step 4 — Storing Tank



- Take the cover off of the resin tank box
 - Make sure the label on the cover and box match the resin tank being put in
- Gently place the tank in the box and place the cover back on
- Place the tank box in the specified storage location

Step 5 — Opening Replacement Tank




- Open the box and remove the cover from the tank

Step 6 — Installing Tank






- After confirming the integrity of the tank place it in the printer
- Line up the tracks on the bottom of the tank with their mates on the printer
- Push the tank forward until you feel the tank move into place

Step 7 — Installing Tank II





- The printer should automatically recognize the resin that is inside the tank from the data connector
 - ⓘ If the printer doesn't recognize the tank pull it out and try again
 - ✦ If the problem persists talk to your peers or contact [Formlabs support](#) for guidance on how to proceed

Step 8 — Retrieve Cartridge



- Retrieve the cartridge from the specified storage location
 - If the material is not there, get a new cartridge from storage
- Remove the orange tab from the bottom nipple and place it in the same box that you just got the tank out of
- ① If you open a new cartridge you'll need to cut the bottom nipple so that it opens properly
 - Turn the cartridge upside down and use a razor knife to trace the pre-cut line until you're able to open the nipple and see into the cartridge

Step 9 — Inserting Cartridge



- Orient the cartridge so that the label faces away from you
- Proceed to lower the cartridge into place at the back of the machine
- The machine should automatically recognize the cartridge just like the tank so once it does you're all set